

# FAQs → HOW DOES IT WORK?

While you are flying **the Flyboard**, your PWC and its operator simply follow you.

The Flyboard is powered by the thrust of your personal watercraft (PWC)

The Flyboard will work with **Seadoo, Kawasaki, Yamaha and Honda.**

MAX  
40 FEET  
(FEELS LIKE 80 FEET!)

Hose is tethered to the front of the PWC.

55 FOOT LONG HOSE

An **OPTIONAL** kit allows the pilot to control the PWC throttle from the air (otherwise the PWC rider controls the throttle)

YOU CAN EASILY CONVERT **FROM PWC TO FLYBOARD** AND **BACK** IN MINUTES.

Its recommended that your PWC has a minimum of 100 h.p.  
**IDEAL IS 130 H.P. OR GREATER**